




Slim Straight Electric Screwdriver Model 0801SES

Number used	Technical code	CODE	Name of the piece	ROW
1	01-0801SES	01	ring circlip	1
1	02-0801SES	02	lock sleeve	2
1	03-0801SES	03	lock sleeve spring	3
1	04-0801SES	04	torque adjustment sleeve	4
3	05-0801SES	05	position pins	5
1	06-0801SES	06	torque block	6
1	07-0801SES	07	board	7
1	08-0801SES	08	washer	8
1	09-0801SES	09	torque spring	9
1	10-0801SES	10	washer	10
1	11-0801SES	11	cabinet	11
1	12-0801SES	12	screw	12
1	13-0801SES	13	pin	13
1	14-0801SES	14	main axle	14
2	15-0801SES	15	stell ball	15
1	16-0801SES	16	front bearig	16
1	17-0801SES	17	rear bearing	17
1	18-0801SES	18	circlip	18
1	19-0801SES	19	rolling bearings	19
1	20-0801SES	20	inner gear sleeve	20
8	21-0801SES	21	flat bearing	21
1	22-0801SES	22	bearing pedestal	22
1	23-0801SES	23	circlip	23
1	24-0801SES	24	planet carrier	24
1	25-0801SES	25	planet gear	25
1	26-0801SES	26	planet carrier	26
1	27-0801SES	27	washer	27
1	28-0801SES	28	motor gear	28
1	29-0801SES	29	screw	29
1	30-0801SES	30	connector bar	30
1	31-0801SES	31	motor	31
1	32-0801SES	32	riversible switch cap	32

Slim Straight Electric Screwdriver Model 0801 SES				
Number used	Technical code	CODE	Name of the piece	ROW
1	33-0801SES	33	reversible switch	33
1	34-0801SES	34	circuit board	34
1	35-0801SES	35	start switch	35
1	36-0801SES	36	handle cap	36
1	37-0801SES	37	handle housing	37
1	38-0801SES	38	screw	38
1	39-0801SES	39	press button spring	39
3	40-0801SES	40	press button	40
2	41-0801SES	41	hanging ring	41
2	42-0801SES	42	cable wire only	42
3	43-0801SES	43	speed controller	43
1	44-0801SES	44	spring balancer	44
1	45-0801SES	45	circlip	45
1	46-0801SES	46	plug	46
1	47-0801SES	47	speed controller down housing	47
1	48-0801SES	48	speed controller up housing	48
1	49-0801SES	49	speed controller board	49
4	50-0801SES	50	screws	50
1	51-0801SES	51	label	51
1	52-0801SES	52	label	52
1	53-0801SES	53	label	53
1	54-0801SES	54	label	54