










20V Brushless Impact Drill (LI-ion) Model(9622BHS)

Number used	Technical code	CODE	Name of the piece	ROW
1	01-9622BHS	01	Chuck screw	1
1	02-9622BHS	02	Chuck	2
4	03-9622BHS	03	Screw	3
3	04-9622BHS	04	Screw	4
1	05-9622BHS	05	Platen	5
1	06-9622BHS	06	Torsion cup gear splinter	6
1	07-9622BHS	07	Output shaft	7
1	08-9622BHS	08	Impact spring	8
1	09-9622BHS	09	Washer	9
1	10-9622BHS	10	Bearing	10
1	11-9622BHS	11	Circlip	11
21	12-9622BHS	12	Steel ball	12
1	13-9622BHS	13	Support	13
1	14-9622BHS	14	Moving ratchet	14
1	15-9622BHS	15	Static ratchet	15
1	16-9622BHS	16	Forward/Reverse Shuttle	16
1	17-9622BHS	17	Housing	17
11	18-9622BHS	18	Screw	18
1	19-9622BHS	19	Upper torsion cup	19
1	20-9622BHS	20	Lower torsion cup	20
1	21-9622BHS	21	Threaded ring	21
1	22-9622BHS	22	Spring	22
1	23-9622BHS	23	Platen	23
1	24-9622BHS	24	Mode adjust ring	24
1	25-9622BHS	25	Shift ring	25
2	26-9622BHS	26	Shift splinter	26
1	27-9622BHS	27	Aluminium gear box	27
12	28-9622BHS	28	Steel ball	28
6	29-9622BHS	29	Pin	29
1	30-9622BHS	30	Retaining Ring	30
1	31-9622BHS	31	Spring	31
1	32-9622BHS	32	Self-locking block	32

20V Brushless Impact Drill (LI-ion) Model(9622BHS)

Number used	Technical code	CODE	Name of the piece	ROW
1	33-9622BHS	33	Washer	33
5	34-9622BHS	34	Torsion column	34
1	35-9622BHS	35	Bearing	35
1	36-9622BHS	36	Inner gear ring III	36
1	37-9622BHS	37	Shaft lock planetary carrier	37
5	38-9622BHS	38	Planetary gear III	38
1	39-9622BHS	39	Oil deflector	39
1	40-9622BHS	40	Fixed ring gear	40
1	41-9622BHS	41	Variable speed gear	41
1	42-9622BHS	42	Single gear disc	42
5	43-9622BHS	43	Planetary gear	43
1	44-9622BHS	44	Sun gear	44
3	45-9622BHS	45	Planetary gear	45
3	46-9622BHS	46	Roller pin	46
1	47-9622BHS	47	Gear box	47
4	48-9622BHS	48	Screw	48
1	49-9622BHS	49	Speed Selector lever	49
1	50-9622BHS	50	Motor gear	50
1	51-9622BHS	51	Rotor	51
1	52-9622BHS	52	Speed Selector splinter	52
1	53-9622BHS	53	Speed Selector	53
1	54-9622BHS	54	Stator	54
1	55-9622BHS	55	Rear cover	55
1	56-9622BHS	56	PCBA	56
1	57-9622BHS	57	Battery Connector Block	57
1	58-9622BHS	58	Switch	58
2	59-9622BHS	59	Nut	59
1	60-9622BHS	60	Lampshade	60
1	61-9622BHS	61	Screw	61
1	62-9622BHS	62	gear box assembly	62
1	63-9622BHS	63	belt	63
1	64-9622BHS	64	hook	64

20V Brushless Impact Drill (LI-ion) Model(9622BHS)

Number used	Technical code	CODE	Name of the piece	ROW
1	65-9622BHS	65	label	65
1	66-9622BHS	66	battery	66
1	67-9622BHS	67	charger	67
1	68-9622BHS	68	auxiliary handle	68
1	69-9622BHS	69	movable clamp block	69
1	70-9622BHS	70	fixed clamp block	70
1	71-9622BHS	71	spring	71
1	72-9622BHS	72	pin	72

20V Brushless Impact Drill (LI-ion) Model(9622BHS)

Number used	Technical code	CODE	Name of the piece	ROW
1	66-1-9622BHS	66-1	Battery pack button	70
1	66-2-9622BHS	66-2	Housing cover	71
2	66-3-9622BHS	66-3	Sponge	72
1	66-4-9622BHS	66-4	Nickel piece	73
1	66-5-9622BHS	66-5	Nickel piece	74
1	66-6-9622BHS	66-6	Nickel piece	75
1	66-7-9622BHS	66-7	Spring	76
1	66-8-9622BHS	66-8	.PCB assy	77
2	66-9-9622BHS	66-9	Battery pack contact plate	78
2	66-10-9622BHS	66-10	Battery pack contact plate	79
2	66-11-9622BHS	66-11	Tapping screw	80
1	66-12-9622BHS	66-12	PCB fixed plate	81
10	66-13-9622BHS	66-13	Cell	82
1	66-14-9622BHS	66-14	PCB fixed plate	83
1	66-15-9622BHS	66-15	Nickel piece	84
1	66-16-9622BHS	66-16	Nickel piece	85
1	66-17-9622BHS	66-17	Nickel piece	86
1	66-18-9622BHS	66-18	Button	87
1	66-19-9622BHS	66-19	Lamp cover	88
1	66-20-9622BHS	66-20	Electric quantity display P	89
1	66-21-9622BHS	66-21	Housing support	90
4	66-22-9622BHS	66-22	Tapping screw	91
1	66-23-9622BHS	66-23	label	92

20V Brushless Impact Drill (LI-ion) Model(9622BHS)

Number used	Technical code	CODE	Name of the piece	ROW
1	01-9622BHS	01	Charger housing cover	70
1	02-9622BHS	02	ousing contact plate holde	71
1	03-9622BHS	03	Plate	72
7	04-9622BHS	04	Tapping screw	73
1	05-9622BHS	05	.PCB assy	74
1	06-9622BHS	06	Charger housing	75
4	07-9622BHS	07	Tapping screw	76
1	08-9622BHS	08	cabel	77
1	09-9622BHS	09	label	78
1	10-9622BHS	10	label	79
1	11-9622BHS	11	label	80