




3002				
Number used	Technical code	CODE	Name of the piece	ROW
1	01-3002	01	lock cap	1
1	02-3002	02	spring	2
4	03-3002	03	screw ST4.2X18	3
1	04-3002	04	head capsule	4
1	05-3002	05	O-ring ϕ 4.5	5
1	06-3002	06	lock pin	6
1	07-3002	07	needle bearing HK0810	7
1	08-3002	08	bull gear	8
1	09-3002	09	Stop ring ϕ 32	9
1	10-3002	10	bearing 6201	10
1	11-3002	11	O-ring ϕ 48.7	11
1	12-3002	12	bearing chock	12
4	13-3002	13	screw M4X14	13
1	14-3002	14	dust cap	14
1	15-3002	15	output shaft	15
1	16-3002	16	screw M5X20	16
1	17-3002	17	guard	17
1	18-3002	18	nut M5	18
1	19-3002	19	lower platen	19
1	20-3002	20	Upper platen	20
1	21-3002	21	wrench	21
1	22-3002	22	nut M6	22
1	23-3002	23	pinion	23
1	24-3002	24	O-ring ϕ 22.4	24
1	25-3002	25	flat gasket	25
1	26-3002	26	bearing 608	26
1	27-3002	27	flat gasket	27
1	28-3002	28	bearing cover	28
3	29-3002	29	screw M4X10	29
2	30-3002	30	screw ST2.9X6.5	30
1	31-3002	31	Wind deflector	31
2	32-3002	32	rubber column	32

3002				
Number used	Technical code	CODE	Name of the piece	ROW
1	33-3002	33	armature	33
1	34-3002	34	stator	35
1	35-3002	35	Insulating retaining ring	36
1	36-3002	36	bearing 607	37
1	37-3002	37	bearing bush	38
1	38-3002	38	housing	39
1	39-3002	39	Self-stopping carbon brush	40
1	40-3002	40	capacitor	41
2	41-3002	41	brush yoke	42
2	42-3002	42	screw ST3.5X6.5	43
4	43-3002	43	carbon brush	44
1	44-3002	44	coil spring	45
1	45-3002	45	Cable clamp	46
1	46-3002	46	switch	47
3	47-3002	47	screw ST4.2X13	48
1	48-3002	48	Switch connecting rod	49
1	49-3002	49	spring	50
1	50-3002	50	Switch push button	51
1	51-3002	51	rear cowl	52
1	52-3002	52	cable sheath	53
1	53-3002	53	cable	54
1	54-3002	54	handle	55
1	55-3002	55	lable	56
1	56-3002	56	lable	57