




3003				
Number used	Technical code	CODE	Name of the piece	ROW
1	01-3003	01	lock cap	1
1	02-3003	02	spring	2
4	03-3003	03	screw ST4.2X18	3
1	04-3003	04	head capsule	4
1	05-3003	05	O-ring ϕ 4.5	5
1	06-3003	06	lock pin	6
1	07-3003	07	needle bearing HK0810	7
1	08-3003	08	bull gear	8
1	09-3003	09	Stop ring ϕ 32	9
1	10-3003	10	bearing 6201	10
1	11-3003	11	O-ring ϕ 48.7	11
1	12-3003	12	bearing chock	12
4	13-3003	13	screw M4X14	13
1	14-3003	14	dust cap	14
1	15-3003	15	output shaft	15
1	16-3003	16	screw M5X20	16
1	17-3003	17	guard	17
1	18-3003	18	nut M5	18
1	19-3003	19	lower platen	19
1	20-3003	20	Upper platen	20
1	21-3003	21	wrench	21
1	22-3003	22	nut M6	22
1	23-3003	23	pinion	23
1	24-3003	24	O-ring ϕ 22.4	24
1	25-3003	25	flat gasket	25
1	26-3003	26	bearing 608	26
1	27-3003	27	flat gasket	27
1	28-3003	28	bearing cover	28
3	29-3003	29	screw M4X10	29
2	30-3003	30	screw ST2.9X6.5	30
1	31-3003	31	Wind deflector	31
2	32-3003	32	rubber column	32

3003				
Number used	Technical code	CODE	Name of the piece	ROW
1	33-3003	33	armature	33
1	34-3003	35	stator	34
1	35-3003	36	Insulating retaining ring	35
1	36-3003	37	bearing 607	36
1	37-3003	38	bearing bush	37
1	38-3003	39	housing	38
2	39-3003	40	carbon brush	39
1	40-3003	41	capacitor	40
2	41-3003	42	brush yoke	41
4	42-3003	43	screw ST3.5X6.5	42
2	43-3003	45	coil spring	43
1	44-3003	46	Cable clamp	44
1	45-3003	47	switch	45
3	46-3003	48	screw ST4.2X13	46
1	47-3003	49	Switch connecting rod	47
1	48-3003	50	spring	48
1	49-3003	51	Switch push button	49
1	50-3003	52	rear cowl	50
1	51-3003	53	cable sheath	51
1	52-3003	54	cable	52
1	53-3003	55	Auxiliary handle	53
1	54-3003	56	Label	54
1	55-3003	57	Label	55