




9530				
Number used	Technical code	CODE	Name of the piece	ROW
4	01-9530	1	-Phillips pan head self tapping screw ST3x14	1
1	02-9530	2	End cap	2
1	03-9530	3	Motor rotor assembly	3
1	04-9530	4	Motor gear	4
1	05-9530	5	Stator	5
1	06-9530	6	housing	6
1	07-9530	7	Aluminum front cover	7
1	08-9530	8	O-ring $\Phi 48 \times \Phi 1.5$	8
1	09-9530	9	Bearing	9
1	10-9530	10	Washer	10
1	11-9530	11	Internal gear	11
1	12-9530	12	Wire retaining ring	12
3	13-9530	13	Planetary gear shaft	13
3	14-9530	14	Planetary gear	14
1	15-9530	15	Hammer assembly	15
1	16-9530	16	Output shaft	16
1	17-9530	17	Flat washer	17
1	18-9530	18	Bearing 2	18
1	19-9530	19	O-ring $\Phi 21 \times \Phi 2$	19
1	20-9530	20	Head housing	20
4	21-9530	21	-Phillips pan head self tapping screw ST4x16 (with spring washer)	21
1	22-9530	22	Forward/reverse switch knob	22

9530				
Number used	Technical code	CODE	Name of the piece	ROW
1	23-9530	23	Switch	23
1	24-9530	24	Light cover	24
1	25-9530	25	Controller	25
1	26-9530	26	Battery control board	26
2	27-9530	27	Rubber pillar	27
1	28-9530	28	Battery terminal	28
9	30-9530	30	-Phillips pan head self tapping screw ST3x10	29
2	31-9530	31	Battery pack	30
1	32-9530	32	charger	31
1	33-9530	33	hook	32
2	34-9530	34	nut	33
2	35-9530	35	screw	34
1	36-9530	36	label	35