






TOSAN PART
Customer Services







Screw Drill 9623				
Number used	Technical code	CODE	Name of the piece	ROW
1	1-9623	01	Left-hand Screw	1
2	2-9623	02	Washer	2
1	3-9623	03	Chuck	3
4	4-9623	04	Screw	4
3	5-9623	05	Screw	5
1	6-9623	06	Plate	6
1	7-9623	07	Triangular Bracket	7
2	8-9623	08	Spring	8
2	9-9623	09	Ratchet Pin	9
1	10-9623	10	Graduated Plastic	10
1	11-9623	11	Shaft	11
1	12-9623	12	Bearing 61900	12
1	13-9623	13	Upper Striker / Hammer	13
1	14-9623	14	Spring Cover	14
1	15-9623	15	spring	15
1	16-9623	16	Lower Striker / Hammer	16
1	17-9623	17	Adjustment Nut	17
6	18-9623	18	Spring	18
1	19-9623	19	Mode Adjustment Plastic	19
1	20-9623	20	Adjustment Gear Washer	20
1	21-9623	21	Adjustment Washer	21
6	22-9623	22	Pin	22
1	23-9623	23	Bearing 61800	23
3	24-9623	24	spring	24
3	25-9623	25	pin	25
1	26-9623	26	gear box	26
6	27-9623	27	pin	27
1	28-9623	28	washer	28
1	29-9623	29	Locking Bush	29
3	30-9623	30	Cylindrical Pin	30
1	31-9623	31	Locking Plate / Shim	31
1	32-9623	32	Third Sun Gear Holder	32

Screw Drill 9623

Number used	Technical code	CODE	Name of the piece	ROW
1	33-9623	33	Clutch Gear	33
6	34-9623	34	Third Sun Gear	34
1	35-9623	35	plate	35
1	36-9623	36	o-ring	36
1	37-9623	37	Second Sun Gear Holder	37
5	38-9623	38	Second Sun Gear	38
5	39-9623	39	Ball Cage / Retainer	39
1	40-9623	40	Speed Change Gear	40
1	41-9623	41	First Sun Gear Holder	41
4	42-9623	42	First Sun Gear	42
4	43-9623	43	Ball Cage / Retainer	43
1	44-9623	44	flange	44
1	45-9623	45	Mode Change Spring	45
1	46-9623	46	Speed Change Chassis	46
1	47-9623	47	Speed Change Chassis Spring	47
3	48-9623	48	screw	48
1	49-9623	49	metal plate	49
1	50-9623	50	stator	50
1	51-9623	51	complete rotor	51
1	53-9623	53	end housing	52
13	54-9623	54	screw	53
3	55-9623	55	rubber pin	54
1	56-9623	56	pin	55
1	57-9623	57	Left and Right Chassis	56
1	58-9623	58	housing	57
1	59-9623	59	control board	58
1	60-9623	60	Battery Connection Base	59
1	61-9623	61	Switch	60
1	62-9623	62	Cover Cap	61
1	63-9623	63	Sponge	62
1	64-9623	64	spring	63
1	65-9623	65	LED Cover	64

Screw Drill 9623				
Number used	Technical code	CODE	Name of the piece	ROW
1	66-9623	66	LED Transparent Sheet / Lens	65
1	67-9623	67	Control Panel	66
1	68-9623	68	Auxiliary Handle	67
1	69-9623	69	Left Clamp / Clip	68
1	70-9623	70	Right Clamp / Clip	69
1	71-9623	71	pin	70
2	72-9623	72	Battery	71
1	73-9623	73	Charger	72
1	74-9623	74	Label	73
2	75-9623	75	screw	74
2	76-9623	76	Nut	75
1	77-9623	77	Hook	76
1	78-9623	78	Strap	77
1	79-9623	79	Auxiliary Handle Assembly	78
1	72.1-9623	72.1	Battery pack button	79
1	72.2-9623	72.2	Housing cover	80
2	72.3-9623	72.3	Sponge	81
1	72.4-9623	72.4	Nickel piece	82
1	72.5-9623	72.5	Nickel piece	83
1	72.6-9623	72.6	Nickel piece	84
1	72.7-9623	72.7	Spring	85
1	72.8-9623	72.8	PCB assy.	86
2	72.9-9623	72.9	Battery pack contact plate	87
2	72.10-9623	72.10	Battery pack contact plate	88
2	72.11-9623	72.11	Tapping screw	89
1	72.12-9623	72.12	PCB fixed plate	90
10	72.13-9623	72.13	Cell	91
1	72.14-9623	72.14	PCB fixed plate	92
1	72.15-9623	72.15	Nickel piece	93
1	72.16-9623	72.16	Nickel piece	94
1	72.17-9623	72.17	Nickel piece	95
1	72.18-9623	72.18	Button	96

Screw Drill 9623				
Number used	Technical code	CODE	Name of the piece	ROW
1	72.19-9623	72.19	Lamp cover	97
1	72.20-9623	72.20	Electric quantity display PCB	98
1	72.21-9623	72.21	Housing support	99
4	72.22-9623	72.22	Tapping screw	100
1	72.23-9623	72.23	label	101
1	72.24-9623	72.24	label	102
1	72.25-9623	72.25	label	103
1	73.1-9623	73.1	Charger housing cover	104
1	73.2-9623	73.2	Housing contact plate holder	105
1	73.3-9623	73.3	Plate	106
7	73.4-9623	73.4	Tapping screw	107
1	73.5-9623	73.5	PCB assy.	108
1	73.6-9623	73.6	Charger housing	109
4	73.7-9623	73.7	Tapping screw	110
1	73.8-9623	73.8	cabel	111
1	73.9-9623	73.9	label	112
1	73.10-9623	73.10	label	113
1	73.11-9623	73.11	label	114